

Make your life easier



Image

- Photo accessories - Camera bags



Hold-all bag with memory shape foam inside.

1 front pocket for accessories and 1 inner mesh pocket for memory cards. Pad at the base of the bag to protect the camera against the shocks. Rain cover.

BOX CONTENTS









Characteristics















universal

High-strength polyester + memory shape foam

12

18



10



Packing: 2 Net weight (g): 598 Weight with packaging (g): 611 Product size (cm): Packing size (cm): 24x16x17







Make your life easier





Packing: 2 Net weight (g): 598 Weight with packaging (g): 611 Product size (cm): Packing size (cm): 24x16x17



