

## Make your life easier



Home

- Cleaning - Other cleaning



For cleaning your CD player.

Recorded vocal instructions High performance dry system Regular cleaning every 10 to 15 hours of use is recommended to keep your devices in top condition

**BOX CONTENTS** 









## **Characteristics**



All CD players



Packing: 10

Net weight (g): 74

Weight with packaging (g): 93

Product size (cm): Packing size (cm): 14.5x1.5x15



